



POSITION MONITOR FOR BOARDS

2443.14.55.



Mounting example



Material:
Steel

Note:
See following pages for accessories.

Attention:
At least two position monitors must be installed crosswise. In case of large parts, such as the side part, a third position monitor should be placed. The position monitors should be placed in such a way that a perfect querying of the sheet metal part is guaranteed. Position monitors should be arranged a minimum of 5 mm away from the pulling or locking bars and not within the range of strong sheet movement.

2443.14.55. Position monitor for boards

Order No	l	Shape
2443.14.55.1	145	A
2443.14.55.2	145	B
2443.14.55.3	185	A
2443.14.55.4	185	B
2443.14.55.25	225	A
2443.14.55.26	225	B